



# HP Mini 210-1199DX Keyboard Key Replacement

HP Mini 210-1199DX keyboard piece has broken off, or in need of replacement.

Written By: Phillip Winston



## INTRODUCTION

This guide will show you how to replace missing or broken keys from the keyboard of a HP Mini 210-1199DX.



### TOOLS:

- [Cotton Swab](#) (1)
- [iFixit Opening Tools](#) (1)



### PARTS:


- [keyboard key](#) (1)
-

## Step 1 — Keyboard pieces



- Locate the broken key(s) and make sure there's nothing blocking it or jammed in the slots. Insert the key into the key slot.

## Step 2



- Take a clean cotton swab and make sure to clean out both the key itself along with the key slot. Remove anything that may be jamming or interfering with the key.



## Step 3



- With the key slot clear, press the key into the slot firmly. Upon hearing a click press it a few times to confirm that it is fully attached.

---

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 02:13:45 PM.